





Firmware update by USB

MENU

Recommend Manual USB Update

- (1) Current Version confirmation
- (2) Access to Download site
- (3) Download and read the Instruction
- (4) Download and prepare USB
- (5) Update to "Setup", On Screen Display,



(1) Current version confirmation



(2) Access to Download site by PC

<https://www.onkyousa.com/Downloads/firmware.php>

Choose the model

TX-NR676		Firmware Instructions
TX-NR676		Firmware USB Download

(3) Download and read the Instruction

TX-NR676		<u>Firmware Instructions</u>
----------	---	------------------------------

Read first, the Instruction.



- 1) Firmware Version
- 2) Improve items
- 3) How to prepare the USB Memory Device
 - Download the zipped file
 - Extract
 - Move to USB device

(4) Download and prepare USB

TX-NR676		<u>Firmware USB Download</u>
----------	---	------------------------------

- Download the zipped file to PC desktop
- Extract on desktop
- Move to USB device All files

(5) Setup Menu (Front panel or Remote controller)



(6) Start Update

